



## User Manual


### For solar model of wind power generator

Welcome, and thank you for choosing our products! Before operating your solar model of wind power generator, please read the following instructions carefully, and keep save this manual for future reference.

#### 1. Package contents


Your package should contain following components:

- 1) Pedestal 1PC
- 2) Column 1PC
- 3) Motor shell with fan socket 1PC
- 4) Fans 3PCS
- 5) Cowling 1PC



If anything listed above is missing or damaged, please contact the dealer from whom you purchased.


#### 2. Assembly



- 1) Pass the wire of the motor shell through the smaller end of the column, and insert the motor shell into the column.



- 2) Open the baseboard of the pedestal and fetch out the fans and cowling.



- 3) Insert another end of the column into the pedestal and twist to fix it. Pull the wire and insert it into the socket. Close the baseboard of the pedestal.

- 4) Insert the fans into the fans socket.
- 5) Put on the cowling to the fans socket.
- 6)



OK, now you have finished the assembling! Congratulations and thank you again for choosing our products!